### **BP15P12C Tech Sheet**

#### **Balboa Water Group**

Part Number: 56312 4kW 800 Incoloy Element

**56313** With 4kW Titanium Element

Compatible Plumbing Kits (Coupling nuts and seals included)

55911 2" Tailpieces (2-Speed Pump 1) 55914 1.5" Tailpieces (2-Speed Pump 1)

55912 1" Tailpiece Inserts (Circ)

One Direct Circ Pump Coupling and one 1" Tailpiece Insert

UL System Model: BP15-BP15P12C-BJ Software ID: M100\_200 V6

Software Version: 6.0

Hex File: BP1500\_6.0\_BP15P12C.hex

Configuration Signature: EB5C7A70

Eng. Project: 3882

Base PCBs / PCBA's:

Power Board: 22117\_B / 56325 Logic Board: 22121\_E / 56314

Control Panels:

TP 600 55673-05 Software Version 2.3 and later

TP400T 50260

Software Version 2.4 and later

TP400W 50259

Software Version 2.4 and later



User Interface and Programming Guide:

http://service.balboa-instruments.com/zz40940\_download.zip



## **System Revision History**

Part #	EPN	Date	Originator	Changes Made
56312	3879	08-08-12	BWG	New Revolution system with 2-Speed Pump 1 plus Circ., plus other setups
and				that do not require Pump 2 or Blower.
56313				



### **Plumbing Fittings**





#### 2" Tailpiece kit PN 55911.

Standard 2" sockets to glue up to 2" PVC pipe.





Not Immediately Available.

#### 1.5" Tailpiece kit PN 55914.

1.5" sockets to glue up to 1.5" PVC pipe with the I.D.

Be sure to orient the fittings so that the insert is at the 12:00 position to prevent trapped air.





#### 1" Circ Pump Insert kit PN 55912.

1" barb fittings for use with 1" tubing.

Be sure to orient the fittings so that the insert is at the 12:00 position to prevent trapped air.





Not Immediately Available.

#### 1" Circ Pump Insert kit PN 55913.

One fitting for direct coupling to the threaded suction of an appropriately-sized circ pump. A 1" barb fitting for use with 1" tubing is used on the other end of the heater.

Be sure to orient the fittings so that the insert is at the 12:00 position to prevent trapped air.



## Setup 1 @ 240V (As Manufactured)

#### **Power Requirements:**

240VAC, 60Hz, 40A, Class A GFCI-protected service (Circuit Breaker rating = 50A max.) 4 wires (Hot-Line 1, Hot-Line 2, Neutral, Ground)

#### System Ouputs:

Pump 1 240VAC 2-Speed 12A max 30-minute timer for Low Speed, 15 Minutes for High Speed

Circ Pump 240VAC 1-Speed 5A max Programmable Filtration Cycles + Polling

This is the heater pump and must be the same voltage as the Ozone

Must deliver a minimum of 20 GPM through heater

Ozone 240VAC .5A max Uses the same relay as the Circ Pump


Must be the same voltage as heater pump

Spa Light 12VAC On/Off 1A max 4-Hour timer.


Heater 4kW @ 240VAC

Misc. J23 & J32 120VAC 4A max Hot output (Stereo). Fused equipment or in-line fuse required.

#### Wiring Diagram and Settings



Buttons and LEDs labeled "AUX" will not operate any equipment.





Refer to Page 3 to choose a suitable Plumbing Kit.

### Setup 1 @ 120V

#### **Power Requirements:**

120/240VAC, 60Hz, 16/40A, Class A GFCI-protected service (Circuit Breaker = 20/50A max.), 3 or 4 wires [hot, hot (optional), neutral, ground]. **Do not use this setup with a 3 kW heater.** 

#### System Ouputs:

Pump 1 120VAC 2-Speed 12A max 30-minute timer for Low Speed, 15 Minutes for High Speed

Circ Pump 120VAC 1-Speed 1.5A max Programmable Filtration Cycles + Polling

This is the heater pump and must be the same voltage as the Ozone

Must deliver a minimum of 20 GPM through heater

Ozone 120VAC .5A max Uses the same relay as the Circ Pump


Must be the same voltage as heater pump

Spa Light 12VAC On/Off 1A max 4-Hour timer.

Heater 1kW @ 120VAC or 4kW @ 240VAC


Misc. J23 & J32 Not Applicable with 120V Heater.

#### Wiring Diagram and Settings



#### 120v to 240v heater conversion instructions:

- 1, Conversion must be performed by a qualified, licensed electrician.
- 2, Disconnect from power and remove power cord.
- 3, Completely remove jumper wire between J29 and J33 and discard.
- 4, Install 240V power conductors; Line 1, Line 2 and Neutral to main terminal block (TB1)



Output Splitter Part Number 22934 must be used.



Refer to Page 3 to choose a suitable Plumbing Kit.

### Setup 2 @ 240V

#### **Power Requirements:**

240VAC, 60Hz, 40A, Class A GFCI-protected service (Circuit Breaker rating = 50A max.) 4 wires (Hot–Line 1, Hot–Line 2, Neutral, Ground)

#### System Ouputs:

Pump 1 240VAC 2-Speed 12A max 30-minute timer for Low Speed, 15 Minutes for High Speed

This is the heater pump and must deliver a minimum of 20 GPM through heater

Ozone 240VAC .5A max Uses the same relay as the Circ Pump


Must be the same voltage as heater pump

Spa Light 12VAC On/Off 1A max 4-Hour timer.

Heater 4kW @ 240VAC

Misc. J23 & J32 120VAC 4A max Hot output (Stereo). Fused equipment or in-line fuse required.

#### Wiring Diagram and Settings



Buttons and LEDs labeled "AUX" will not operate any equipment.

# Software Configuration Changes based on Default Feature Orig. Setup 1 Changes to

J14 . . . . . Ozone and Circ\*. . . . . Ozone Only

\*Output Splitter 22934 is not needed in this configuration.



Refer to Page 3 to choose a suitable Plumbing Kit.

### Setup 2 @ 120V

#### **Power Requirements:**

120/240VAC, 60Hz, 16/40A, Class A GFCI-protected service (Circuit Breaker = 20/50A max.), 3 or 4 wires [hot, hot (optional), neutral, ground]. **Do not use this setup with a 3 kW heater.** 

#### System Ouputs:

Pump 1 120VAC 2-Speed 12A max 30-minute timer for Low Speed, 15 Minutes for High Speed

This is the heater pump and must deliver a minimum of 20 GPM through heater

Ozone 120VAC .5A max Uses the same relay as the Circ Pump


Must be the same voltage as heater pump

Spa Light 12VAC On/Off 1A max 4-Hour timer.

Heater 1kW @ 120VAC or 4kW @ 240VAC

Misc. J23 & J32 Not Applicable with 120V Heater.

#### Wiring Diagram and Settings



# Software Configuration Changes based on Default Feature Orig. Setup 1 Changes to

J14 . . . . . . Ozone and Circ\* . . . . . . Ozone Only

#### 120v to 240v heater conversion instructions:

See Page 5.

BALB@A
water group

Refer to Page 3 to choose a suitable Plumbing Kit.

<sup>\*</sup>Output Splitter 22934 is not needed in this configuration.

### Setup 3 @ 240V

#### **Power Requirements:**

240VAC, 60Hz, 40A, Class A GFCI-protected service (Circuit Breaker rating = 50A max.) 4 wires (Hot–Line 1, Hot–Line 2, Neutral, Ground)

#### System Ouputs:

Pump 1 240VAC 1-Speed 12A max 15-minute timer

Circ Pump 240VAC 1-Speed 5A max Programmable Filtration Cycles + Polling

This is the heater pump and must be the same voltage as the Ozone

Must deliver a minimum of 20 GPM through heater

Ozone 240VAC .5A max Uses the same relay as the Circ Pump


Must be the same voltage as heater pump

Spa Light 12VAC On/Off 1A max 4-Hour timer.

Heater 4kW @ 240VAC

Misc. J23 & J32 120VAC 4A max Hot output (Stereo). Fused equipment or in-line fuse required.


#### Wiring Diagram and Settings



Buttons and LEDs labeled "AUX" will not operate any equipment.

# Software Configuration Changes based on Default Feature Orig. Setup 1 Changes to

J8...... 2-Speed Pump 1 ......1-Speed Pump 1



Output Splitter Part Number 22934 must be used.

Refer to Page 3 to choose a suitable Plumbing Kit.

Blue indicates changes from the original Setup 1 default



### Setup 3 @ 120V

#### **Power Requirements:**

120/240VAC, 60Hz, 16/40A, Class A GFCI-protected service (Circuit Breaker = 20/50A max.), 3 or 4 wires [hot, hot (optional), neutral, ground]. **Do not use this setup with a 3 kW heater.** 

#### System Ouputs:

Pump 1 120VAC 1-Speed 12A max 15-minute timer

Circ Pump 120VAC 1-Speed 1.5A max Programmable Filtration Cycles + Polling

This is the heater pump and must be the same voltage as the Ozone

Must deliver a minimum of 20 GPM through heater

Ozone 120VAC .5A max Uses the same relay as the Circ Pump


Must be the same voltage as heater pump

Spa Light 12VAC On/Off 1A max 4-Hour timer.

Heater 1kW @ 120VAC or 4kW @ 240VAC


Misc. J23 & J32 Not Applicable with 120V Heater.

#### Wiring Diagram and Settings



# Software Configuration Changes based on Default Feature Orig. Setup 1 Changes to

J8.......2-Speed Pump 1 .....1-Speed Pump 1



120v to 240v heater conversion instructions: See Page 5

BALBOA water group

Refer to Page 3 to choose a suitable Plumbing Kit.

Blue indicates changes from the original Setup 1 default

### **Setup Changes with DIP Switch 1 ON**


#### Read and understand these instructions before beginning this process.

Know the Setup Number you want before you power up the spa and wait to power up the spa until you're ready to change the Setup Number.

The system must be in Test Mode, so move Switch 1 to the ON position. The Test Menu will then be available.

Power up the spa, and press any button once to Link the panel. (Note: Switch 1 can be moved to the ON position immediately after power-up, if preferred - Danger! High Voltage will be present!)

**You will have 1 minute** to complete the setup change after you manually exit Priming Mode. (Once familiar with the process, the Setup change should take less than 15 seconds.)



### DANGER! HIGH VOLTAGE WILL BE ACCESSIBLE! SERVICE TECHNICIAN ONLY!

Move DIP Switch 1 (on S1 on the Logic circuit board) to ON.

The system will enter Test Mode.

Moving DIP Switch 1 to OFF will exit Test Mode.



When the panel displays RUN PMPS PURG AIR, press any Temperature button ONCE to exit Priming Mode. You should see "---T" where the T indicates the system is in Test Mode.



Continued on Next Page.



### **Setup Changes – Continued**

Again, You will have 1 minute to complete the setup change after you manually exit Priming Mode.


Immediately after exiting Priming Mode, press this sequence of buttons: Warm\*, Light, Warm, Warm, Warm, Warm. Continue to press Warm until the diplay shows the Setup Number (S-01, S-02, etc.) you want to switch to. When the correct setup number is showing, press Light once, and the system will reset, using the newly-selected Setup from that point on.


Key

Move DIP Switch 1 to the OFF position to take the spa out of Test Mode. °F or °C will replace °T.

Using a permanent marker, write the Setup number on the Setup label mounted inside the system lid (right). This is very important to any service person in the future who may need to replace a circuit board or system and needs to change the Setup on a replacement part while in the field.

NOTE: Changing the Setup may require wiring changes as well - refer to the wiring diagram or wiring diagram addendum.





\*If the Control Panel does not have a Warm (Up) button, but rather a single Temp button, use the Temp button in place of the Warm button in the instruction above. (The flow chart assumes a single Temperature Button.)



#### **General Features**

Feature	Default
Pump 1 in Filter Cycle (Circ Only)	No
Pump 1 Low Timer	30 Minutes
General Pump Timer	15 Minutes
Blower Timer	15 Minutes
Mister Timer (N/A)	15 Minutes
Light Timer	240 Minutes
Circ	Like P1 Low

Cleanup Cycle 30 Minutes

Cleaup as Preference setting Yes

Ozone With Heater Pump\*

Ozone Suppression OFF

Pump Purge 60 Seconds
Blower Purge 30 Seconds
Mister Purge (N/A) 5 Seconds



<sup>\*</sup> The Heater Pump can be either a Circ Pump or Pump 1 Low.

#### **Temperature Features**

### Feature Default

Temperature Display

All temperatures must be specified in °F. The system converts °F to °C dynamically. If Celsius is required for default settings, choose a desired °C value that (after rounding) corresponds to a Fahrenheit value.

°C	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
°F	39	41	43	45	46	48	50	<i>52</i>	54	55	<i>57</i>	59	61	63	64	66	68	70	72
°C	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	
°F	73	<i>75</i>	<i>77</i>	79	81	82	84	86	88	90	91	93	95	97	99	100	102	104	

Hi-Range Min. Set Temp	80°F
Hi-Range Max. Set Temp	104°F
Hi-Range Default Temp*	100°F
Lo-Range Min. Set Temp	50°F
Lo-Range Max. Set Temp	80°F
Lo-Range Default Temp*	70°F
Freeze Threshold	44°F

Temp Lock Type Temp + Settings

### Time Features

Light Cycle Duration\*

Feature	Default
Time Format*	12 Hour
Filter 1 Start Hour*	8:00 PM (20:00)
Filter 1 Duration*	2 Hours
Filter Cycle 2 Default*	OFF
Filter 2 Start Hour*	8:00 AM (08:00)
Filter 2 Duration*	15 Minutes
Light Cycle	Disabled
Light Cycle Default*	OFF
Light Cycle Start Hour*	9:00 PM (21:00)



15 Minutes

<sup>\*</sup>May be changed by end-user (if Enabled)

#### **Reminder Features**

Feature	Default
Reminders Shown*	Yes
Check pH	OFF
Check Sanitizer	OFF
Clean Filter	30 Days
Test GFCI	65 Days
Drain Water	100 Days
Change Cartridge	OFF
Clean Cover	OFF
Treat Wood	OFF
Change Filter	365 Days

### **Special Features**

Feature Default

Special Amperage Rule 1 No Limitation

Special Amperage Rule 2 No Limitation

Drain Mode Disabled
Demo Mode Disabled
Automatic GFCI Test Disabled

Ozone Slaved to Heater Pump Yes in Setups 1 & 3

No in Setup 2



<sup>\*</sup>Editable by end-user

# **TP400 Control Panel Features**Feature TP400T

Button 1	Temperature	Up
Button 2	Jets 1	Down
Button 3	Light 1	Light 1
Button 4	Unused	Jets 1

LED B1	Heat ON	Heat ON
LED B2	Jets 1	Unused
LED B3	Light 1	Light 1
LED B4	Unused	Jets 1

#### **TP400T**

50260

Includes Overlay PN 12511




**TP400W** 

#### **TP400W**

50259

Includes Overlay PN 12510



#### Download the User Interface and Programming Guide here:

http://service.balboa-instruments.com/zz40940\_download.zip

Blue Indicates New Custom Configuration Default (Setup 1)



# TP600 Control Panel Features Feature Default

:: -	
Button 1	Jets 1
Button 2	Unused
Button 3	Flip
Button 4	Up
Button 5	Light 1
Button 6	Down

LED 1	Jets 1
LED 2	Unused
LED 3	Light 1
LED 4	Heat ON

#### **TP600**

55673-05

Includes overlay PN12511



#### Download the User Interface and Programming Guide here:

http://service.balboa-instruments.com/zz40940\_download.zip

Blue Indicates New Custom Configuration Default (Setup 1)



### **Auxilliary Panel Features**

Feature	Default
Aux Button A1	Jets 1
Aux Button A2	Unused
Aux Button A3	Unused
Aux Button A4	Light

AX10 A1	Jets 1	52683-01

AX10 A2 N/A

AX10 A3 N/A


AX10 A4 Light 52766



AX20 A1A2 N/A

AX20 A1A3 N/A

AX20 A1A4 No 0/L 52802



AX40 No 0/L 52799

